




DEL ORO
WATER COMPANY




DELIVERING NATURE'S PRECIOUS RESOURCE

How to Read Your Meter



Reading #1



Reading #2

To calculate usage always read the meter from left to right

Take a meter reading; **reading #1** is **00538800** cubic feet

Take another meter reading; **reading #2** is **00539975** cubic feet

Subtract reading #1 from reading #2:

	00539975	cubic feet
-	00538800	cubic feet
=	1,175	cubic feet used

***NOTE:** the **red dial** on your meter functions as a *leak detector*.

The **red triangle** on your meter also functions as a *leak detector*.

It turns much faster than the red dial or the numbers.

If you can see either dial turning when all water is shut off, you have a leak!